www.vermontsnowguardcompany.com

LAYOUT PATTERN SUGGESTION FOR STANDING SEAM ROOFS

Important: *Do not install snow guards on roofs with pitches less than 3:12*

◊ Place the **first row** of snow guards at or above the exterior load-bearing wall; not on the overhang!

◊ Attach the snow guards to every other seam along the entire length of the roof or over areas that require protection from avalanching snow such as walkways, structures, landscaping, etc.

◊ Place the **second row** of snow guards 15" to 24" above the first row. Attach snow guards to each seam that was skipped in the first row.

◊ **If a third row** is used, the stagger pattern should match that of the first row.

Attaching the snow guards:

◊ Attach snow guards by tightening the supplied set screws using a 3/16" hex bit. Tighten until the tip of the set screw is firmly embedded in the metal. The torque will vary depending on the gauge of the metal and the seam style. **DO NOT** over-tighten or penetrate the seam!

IMPORTANT NOTE: Our snow guards are meant to be used on double-lock seams. Single-lock seams will need to be double-locked (hand crimped) at installation point *before* installing the snow guard.

Snow guards should be installed by a professional roofing contractor.