

## SNOW GUARD INSTALLATION RECOMMENDATIONS

BEFORE APPLYING AN ADHESIVE TO THE BOTTOM OF THE SNOW GUARDS FOLLOW THESE SIMPLE INSTRUCTIONS. CLEAN THE ROOF WHERE YOU INTEND TO PLACE THE SNOW GUARD AS WELL AS THE BOTTOM OF THE SNOW GUARD BY USING XYLENE (XYLOL) OR ISOPROPYL ALCOHOL




FIG. 1

1. EVENLY COAT THE ENTIRE BASE OF THE SNOW GUARD WITH ADHESIVE TO ENSURE THAT WHEN THE GUARD IS SET IN PLACE THE ADHESIVE WILL UNIFORMLY COVER THE ENTIRE BASE OF THE SNOW GUARD AND PROVIDE ADEQUATE "SQUEEZE-OUT" OF ADHESIVE AROUND THE EDGE OF THE BASE OF THE SNOW GUARD. (FIG. 1)



FIG. 2

2. PRESS DOWN FIRMLY ON THE SNOW GUARD TO "SET" SNOW GUARD INTO PLACE TO REMOVE ANY AIR POCKETS AND CAUSE EXTRA ADHESIVE TO FORM AN EDGE SEAL AROUND THE ENTIRE SNOW GUARD. THIS SHOULD ALSO CAUSE ADHESIVE TO EXTRUDE THROUGH SCREW HOLES, RIVETING THE SNOW GUARD IN PLACE. (FIG. 2)



CROSS SECTION  
FASTENER ATTACHMENT SECURE  
SNOW GUARD IN PLACE




CROSS SECTION  
ADHESIVE "RIVETS" SECURE  
SNOW GUARD IN PLACE

FIG. 3

3. AS PER MANUFACTURERS SUGGESTIONS USE STAINLESS STEEL SCREWS WITH NEOPRENE WASHERS TO FIRMLY ANCHOR SNOW GUARD TO SUB ROOF OR PURLINS USING BOTH SUPPLIED HOLES. (FIG. 3)


ONE 10 OZ. TUBE OF ADHESIVE WILL COVER APPROXIMATELY 20 MC2'S OR EAGLE 2'S OR BOSS 3'S



2 HOLES FOR  
ATTACHMENT W/  
FASTENERS

SNOW GUARD HEAD  
2 1/4" WIDE x 2 1/4" HIGH

TYPICAL INSTALLATION METHOD DIAGRAM



METAL ROOF DECK

ROOFING FELT

ROOF SHEATHING

BOSS #3 TYPE SNOW GUARD

ADHERE SNOW GUARD TO ROOF DECK W/ SILICONE OR POLYURETHANE SEALANT

OPTIONAL FASTENER W/ NEOPRENE WASHER ATTACHMENT

BOSS #3 TYPE SNOW GUARD

TOP OF ROOF STRUCTURE

TYPICAL BOSS #3 TYPE CROSS SECTION